



UT281 Series **PRO** True RMS Flex Clamps

UT281 series True RMS flex clamps can measure large current in various harsh and hard to reach environments. It is designed with Rogowski flex coil technology and can test up to 3000A AC current. Being one of UNI-T's PRO Line series, it is designed to meet IP54 and 2m drop proof requirements. Due to its easy operation, accurate reading, stable performance and reliable quality, it is an ideal tool for electricians.



Features

- 2m drop proof, IP54, ETL/Intertek certified 3rd edition CE
- Coil diameter: 0.75cm; bending length: 24.5cm for UT281A and 47.5cm for UT281C
- Large LCD display for clear reading
- True RMS
- Long press INRUSH key for 2s to measure inrush current
- Data hold, backlight, auto power off



	UT281A	UT281C
AC current	30A/300A/3000A	
Resolution	0.01A/0.1A/1A	
Inrush current	0.50A ~ 3000A	
Frequency response	45Hz ~ 500Hz	
Max display count	3000	
Sampling rate	3 times/s	

